

Scan the QR code to verify that you have the latest instructions or visit vaultenclosures.com/instructions



PARTS INCLUDED

a



10-32X3/8 Pan Head (3)



(1)

b



10-32X1/2 Flat Head (6)

f



Cable Cover (1)



10-32x1/2 Pan Head (4)

g



Duraco Adhesive Large Foot (2)

d



6-32x3/8 Flat Head (3)

h



Duraco Adhesive Small Foot (2)

1. REMOVE CABLE COVER



2. ROUTE CABLE



3. REINSTALL THE CABLE COVER

management.



*Route your cable out and into the channels on the mounting plate if your enclosure doesn't support internal cable management.

4. DETERMINE WHICH SET OF HOLES YOU WILL HAVE FOR INSTALLATION





To mount your backplate with no screws showing from the outside, use the included 10-32x1/2 (b) Flal Head screws and mount your backplate from the inside of the backplate.





For assembly of Connect enclosure and base, use the included 10-32x1/2 (c) Pan Head screws and the inner set of holes tomount your enclosure to the base from the backside

SURFACE MOUNTING OPTIONS

Standard
For a non-permanent mounting solution, peel off the film from the bottom of the rubber feet on the base.

Semi-Permanent For a semi-permanent mounting solution, use the (4) duraco pads included with your base. Peel off one side of the film and stick it to the matching rubber foot on the base. Let the adhesive cure onto the base for 3 hours before peeling off the other side and sticking it to your desired surface. Once you have stuck the base down to a surface, let it sit for another 12 hours with NO interaction before use To remove duraco, take a piece of filament such as fishing line or dental floss and run underneath the base in a sawing motion to

cut the adhesive

REFER TO TABLET ENCLOSURE INSTRUCTIONS TO FINISH YOUR SOLUTIONS ASSEMBLY

